Metropolis HV (Motorized)

CONTROL BOX

ASSEMBLY OVERVIEW



8-pin DIN-sockets





Attention:

Before starting the system, please make sure, that the operating voltage of the system conforms with the local power supply. The mains plug of the control has to be connected to a free accessible power supply.


* Plug in - Follow the arrow on the sockets.








METROPOLIS LEGS




BEAM




Aluminium Beam

VERSION




HV version - via motorized




Mount connector to endleg with cap screws.




Place work top on frame.




Bottom view - Attach control panel with S/D screws at the bottom of




Start up - Turn on the main power supply before setting. Once the power is on, display flashes show 000 or ---.




Press one of the memory keys, 1,2,3,4, and the number of the position height is displayed, a double click is heard at the end of memory saved. Repeat the same step of this for other preferred heights.




View up-side-down - a. Push plastic stopper (a) away from leg, b. Push down stopperhead (d) into centre gutter, c. Fit round axis over hexagon shaft inside connector, d. Pull stopper head out of gutter.



Bottom view - Attach worktop with JCBC screws from bottom of top support.




Assemble control box (refer to front page control box assembly).




Press and hold the down button until the lowest position 062 is reached (show in display, stop flashing), system is ready for further programming, the maximum reachable height is 085.




Moving to a saved preferred height - Press and hold one of the




Slide connector into beam.



Bottom view - a. Adjust the length of the beam to fit with worktop, b. Fix cap screws into beam.





Place control box in cabletray, tidy up all the cables into the cabletray



Normal operation - Press and hold up or down until the desired height of the desk has been reached, the display always shows the actual height.







Saving preferred height - 4 preferred heights can be saved.



Move to the desired desk height. Press the store memory 'S'. You will